


social swing round


SSR BASE

installation manual




bejot:


1




2




3




4




5




6




7



8




9




10




11




12




13




14





15





PEOPLE




ADDITIONAL TOOLS








ATTACHED




1




2





3




4







5




6






7



8






9




5

10







5



11




7




12




13







14






15



16




17






18

14



15





Bejot Sp. z o. o.

ul. Wybickiego 2A, Manieczki, 63-112 Brodnica n. Poznania, POLAND

tel.: +48 (61) 281 22 25, e-mail: biuro@bejot.eu

www.bejot.eu

edition 11/2021